

PLANA OUTDOOR TRANSMITTER SWITCH IP55 2 KEYS

The outdoor transmitter switch is wireless, batteryless and waterproof in its IP55 housing. Totally stand-alone, the switch sends a radio signal with the power supplied by pressing ON and OFF keys from the switch, without any maintenance. Associated to a transmitter, it allows to command afar various electrical equipment.

MODULAR AND MOBILE: The transmitter switch can be fixed at any place on a wall and be changed at will. Its adapted bottom allows to fix it on a wall with screws or to stick it with double-sided adhesive tape.

The outdoor transmitter switch avoids tedious two-way switches wiring. It is possible to turn on an electrical device from a switch and to turn off the device from another one. Up to 30 transmitters per receiver, the possibilities are almost infinite without ripping walls and partitions. The applications are also infinite: schools, hotels, hospitals, historic buildings, offices, etc. The box is waterproof (IP 55) for outdoor use.



CODE 10020022 PLANA OUTDOOR TRANSMITTER SWITCH IP55 2 KEYS

SPECIFICATIONS

<i>Transmission power</i>	<i>10mW max</i>
<i>Transmission frequency</i>	<i>868.3MHz</i>
<i>Dimensions</i>	<i>Base 80x80mm x height 65mm</i>
<i>Color</i>	<i>Gray</i>
<i>Operating temperature</i>	<i>From -25°C up to +65°C</i>
<i>Air relative humidity</i>	<i>From 0% up to 95%</i>