

## 1-CHANNEL 10A DIN RAIL RECEIVER

The 1-channel 10A radio DIN RAIL receiver is used to switch various 230V-load electric commuter devices, such as incandescent lamps, halogen lamps, electronic ballasts, vents, heating appliances from a wireless and battery-free EnOcean radio transmitters.

The receiver can process the orders from up to 32 transmitters such as radio switches, window contacts, key card switches, window handles, presence detectors, dry contacts etc.

Based on the wiring, the orders (opened/closed) can be selected for lighting applications (opened) or heating applications (closed).

**RADIO TRANSMITTER MODE:** Each assigned transmitter can be used to change the receiver status, one transmitter can switch on the receiver while another one can switch it off thus creating two-ways switches very simply with no additional electric wires.

**WINDOW CONTACT MODE:** If at least one of the contacts is open, the receiver's status is ON. If both contacts are closed, the receiver's status is OFF. The window contacts send a signal every 15 minutes. The receiver considers the window contacts as closed about 60 minutes after the latest signal has been received.



CODE 10020069 1-CHANNEL 10A DIN RAIL RECEIVER

### SPECIFICATIONS

Antenna	Internal
Power supply	230V AC +- 10% 50Hz
Output load	Max. load 2,300VA (cosφ=1) or 800W (incandescent/halogen lamp), or 300W inductive with cosφ = 0.4-0.6
Frequency	868.3MHz
Inputs	2 LRN buttons (receiver in learning mode) and CLR (reset)
Number of assignable transmitters	Up to 30 transmitters or 2 magnetic window contacts
Dimensions of the module	17.5x97.4x57.8mm
Operating temperature range	-10 up to +45°C
Relative air humidity	0% to 95% of relative humidity, no condensation